Section 6.3 on Facilities and Environmental Conditions Along With Section 6.4 on Equipment





Presented by: Michael Kramer Calibration Program Manager Perry Johnson Laboratory Accreditation, Inc. 24-July-2020



Section 6.3 on Facilities and Environmental Conditions Along With Section 6.4 on Equipment This webinar is being recorded and will be available in it's entirely on the Perry Johnson Laboratory Accreditation Website.

www.pjlabs.com

Go to the link for recorded webinars.

Also individual slides of this and previous presentation are available.

There is a space on your screen to ask questions. Please keep question related to today's topic. At the conclusion of the webinar, received questions will be reviewed and answered.

Duration of webinar is set for one hour.





There are no significant changes between the 2005 and 2017 Standards in this section. When tests or calibrations are performed in facilities outside its permanent control, the new standard requires that environmental and facilities related requirements be met. If not this would be considered a deviation.





6.3.1 The facilities and environmental conditions shall be suitable for the laboratory activities and shall not adversely affect the validity of results.

NOTE Influences that can adversely affect the validity of results can include, but are not limited to, microbial contamination, dust, electromagnetic disturbances, radiation, humidity, electrical supply, temperature, sound and vibration





- **6.3.2** The requirements for facilities and environmental conditions **necessary for the performance of the laboratory activities** shall be documented.
- For example within the internal procedure
- **Environmental conditions required:**
- Temperature to be within the range of 68 °F +/- 2 °F.
- Relative Humidity to be greater than 50 % RH
- The UUT must remain in the laboratory for a minimum of 12 hours prior to calibration to permit thermal stabilization.
- Note: Calibrations are not to be performed if the environmental conditions are outside the allowable limits stated above





6.3.3 The laboratory shall monitor, control and record environmental conditions in accordance with relevant specifications, methods or procedures or where they influence the validity of the results.





6.3.4 Measures to control facilities shall be implemented, monitored and **periodically reviewed** and shall include, but not be limited to:

- a) access to and use of areas affecting laboratory activities;
- b) prevention of contamination, interference or adverse influences on laboratory activities;
- c) effective separation between areas with incompatible laboratory activities.







Section 6.3- Facilities & Environmental Conditions 6.3.5 When the laboratory performs laboratory activities at sites or facilities outside its permanent control, it shall ensure that the requirements related to facilities and environmental conditions of this document are met.

If environmental criteria is out of limits specified by the method, then this needs to be communicated to the customer.

See 7.4.3 – "Handling of Test or Calibration Items"

When the customer requires the item to be tested or calibrated acknowledging a deviation from specified conditions, the laboratory shall include a disclaimer in the report indicating which results may be affected by the deviation





ISO/IEC 17025:2017 updated this section to include:

- Standards, reference materials, reagents, and software are now also considered as equipment (6.4.1).
- Conditions to calibrate equipment are set (6.4.6):
- ➤ if accuracy or uncertainty affect the validity of results
- ➤ if calibration is needed to establish metrological traceability
- Reference to ISO 17034 has been included to emphasis the competence of reference material producers



6.4.1 The laboratory shall have access to equipment (including, but not limited to, measuring instruments, software, measurement standards, reference materials, reference data, reagents, consumables or auxiliary apparatus) that is required for the correct performance of laboratory activities and that can influence the results.





6.4 Equipment

NOTE 1 A multitude of names exist for reference materials and certified reference materials, including reference standards, calibration standards, standard reference materials and quality control materials. **ISO 17034** contains additional information on reference material producers (RMPs). RMPs that meet the requirements of ISO 17034 are considered to be competent. Reference materials from RMPs meeting the requirements of ISO 17034 are provided with a product information sheet/certificate that specifies, amongst other characteristics, homogeneity and stability for specified properties and, for certified reference materials, specified properties with certified values, their associated measurement uncertainty and metrological traceability

NOTE 2 ISO Guide 33 provides guidance on the selection and use of reference materials. ISO Guide 80 provides guidance to produce in-house quality control materials.





6.4.2 When the laboratory uses equipment outside its permanent control, it shall ensure that the requirements for equipment of this document are met;





6.4.3 The laboratory **shall have a procedure** for handling, transport, storage, use and planned maintenance of equipment in order to ensure proper functioning and to prevent contamination or deterioration.





On-site Calibration Services

We can visit your premises to calibrate your equipment to reduce your downtime

Find out more >



6.4.4 The laboratory shall verify that equipment conforms to specified requirements before being placed or returned into service



17025:2005 states Before being placed into service, equipment (including that used for sampling) shall be calibrated or checked to establish that it meets the laboratory's specification requirements



6.4.5 The equipment used for measurement shall be capable of achieving the measurement accuracy and/or measurement uncertainty required to provide a valid result.

Temperature accuracy shall be within 0.5°C

Home Tool:	VALIDACIÓN DE L ISO	D/IEC 17025:201 L17-561	.pdf ×		⑦ Si	ign In	
🖹 🕈 🖶		(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	· · · · · · · · · · · · · · · · · · ·	т	et s	Share	
	rnermodynamic						
	MEASURED INSTRUMENT,	RANGE OR NOMINAL	CALIBRATION AND	CALIBRATION			
	QUANTITY OR GAUGE	APPROPRIATE	CAPABILITY EXPRESSED	AND REFERENCE			
			AS AN UNCERTAINTY (±)	STANDARDS USED			
	Equipment to Measure	-40 °C to 700 °C	0.66 °C	J/K Thermometer with			
	Temperature and	50.051 50.05	0.65.05	type J and type K probes			
	Temperature Sources	-50 °C to 70 °C	0.65 °C	Tharmometer			
	Themometer						
	 The CMC (Calibration and Measurement Capability) stated for calibrations included on this scope of accreditation represents the smallest measurement uncertainty attainable by the laboratory when performing a more or less routine calibration of a nearly ideal device under nearly ideal conditions. It is twoically 						
	expressed at a confidence level of 95 % using a coverage factor k (usually equal to 2). The actual						
	measurement uncertainty associated with a specific calibration performed by the laboratory will typically						
	be larger than t	he CMC for the same calib	ration since capability and perfo	mance of the device being			
	calibrated and th	ne conditions related to the ca	libration may reasonably be expe	cted to deviate from ideal to			
	some degree.						
	2 The lebersterie		liter for all dissiplines for ushial	these and a second its disc			
	2. The laboratories	s range of calibration capab	rd to the largest calibrated stand	ard used in performing the			
	calibration The	low end of this range must be	an attainable value for which the	laboratory has or has access	2 A		
	to the standard referenced. Verification of an indicated value of zero in the absence of a standard is common practice in the procedure for many calibrations but by its definition it does not constitute						
	calibration of ze	ro capacity.					
	a mi (1.100	A A A A A A A A A A A A A A A A A A A	6.4 1 1 1 1 1			



6.4 Equipment

6.4.6 Measuring equipment shall be calibrated when:

— the measurement accuracy or measurement uncertainty affects the validity of the reported results, and/or

— calibration of the equipment is required to establish the metrological traceability of the reported results.

NOTE Types of equipment having an effect on the validity of the reported results can include:

— those used for the direct measurement of the measured, e.g. use of a balance to perform a mass measurement;

— those used to make corrections to the measured value, e.g. temperature measurements;

— those used to obtain a measurement result calculated from multiple quantities.



6.4.7 The laboratory shall establish a calibration program, which shall be reviewed and adjusted as necessary in order to maintain confidence in the status of calibration.

DATE	BY	NEXT DUE
-		
		-
		-
		. D
		_
	_	
		-
		-
		-
	1	-
-		





6.4.8 All equipment requiring calibration or which has a defined period of validity shall be labelled, coded or otherwise identified to allow the user of the equipment to **readily identify** the status of calibration or period of validity.



Rom Name I Trace Tool Bockwell Handness Tesser 4	Location I Inspection	Next Calibration 1. Sep 18, 2019	Performed By	Spec	+ Files +	Repuits	Delete
Trace Tool Rockwell Hardness Tesser 4	Inspection	Sep 18, 2019	lan.	ENGT?	binne.		
Rockwell Hardness Tester 4	Inspection					1211	
		Aug 14, 2019	Golden State Calibration	MET	Norma	Pass	
microwae		Feb 22, 2018	tan	Ave: 27520	None	Pess	
microwat		Peb 22, 2718	san	AM5.2750	None	Pess	
microwac		Feb 22, 2018	kan	AM52790	None	Pass	
Dockwell Hardness Tester 4	inspection	Aug 14, 2010		THE F	Junne	Pass	
microvac		Feb 22, 2018	lan	A145 3790	None	Fast	
Vac Gauge	Vacuum	Jul 12, 2017		1007	None	Para	
microvac		Feb 22, 2018	kan.	4165 4750	None	Paso	
Self Calibration Test	Test.	Jan 19, 2018	Mark	AM5 2790	None	Pess	
					Previous	3 2	3 Nex
	microwsc Bardwald Handhess Taster & microwsc Yan Gauge microwsc Self Calibration Test	MOUNDE Baryad Salahani Tasara a Markata Yan Graga Moraz Saf Grinadon Tast Tast	MCDANC For 22, 2016 Monomed Instances Instances <t< td=""><td>Microsoft 493.2,297.8 An Microsoft Independent wirdsminister 693.2,071.6 Microsoft Microsoft 693.4,071.6 Microsoft</td><td>monose FPS 2004 an Entransiste monose instante indegrada (2004) FPS 2004 Bit 2004 Entransiste monose FPS 2004 Bit 2004 Entransiste Entransiste monose FPS 2004 Bit 2004 Entransiste Entransiste</td><td>monosci No.22.024 Dr. Entra 1000 More monada induzio Antor Marcia No.22.024 Len. Alter More monada induzio Antor Marcia No.22.024 Len. Alter More More More Antor No.22.024 Len. Alter More More</td><td>monoc Frag2.29 and Frag2 Ke And Ke monoc frag2.29 and E Ke K</td></t<>	Microsoft 493.2,297.8 An Microsoft Independent wirdsminister 693.2,071.6 Microsoft Microsoft 693.4,071.6 Microsoft	monose FPS 2004 an Entransiste monose instante indegrada (2004) FPS 2004 Bit 2004 Entransiste monose FPS 2004 Bit 2004 Entransiste Entransiste monose FPS 2004 Bit 2004 Entransiste Entransiste	monosci No.22.024 Dr. Entra 1000 More monada induzio Antor Marcia No.22.024 Len. Alter More monada induzio Antor Marcia No.22.024 Len. Alter More More More Antor No.22.024 Len. Alter More More	monoc Frag2.29 and Frag2 Ke And Ke monoc frag2.29 and E Ke K

From ISO/IEC 17025:2005

Shall be labelled, coded or otherwise identified



6.4.9 Equipment that has been subjected to overloading or mishandling, gives questionable results, or has been shown to be defective or outside specified requirements, shall be taken out of service. It shall be isolated to prevent its use or clearly labelled or marked as being out of service until it has been verified to perform correctly. The laboratory shall examine the effect of the defect or deviation from specified requirements and shall initiate the management of nonconforming work procedure (see 7.10).





6.4.10 When intermediate checks are necessary to maintain confidence in the performance of the equipment, these checks shall be carried out according to a procedure.



Blanks Control Chart





6.4.11 When calibration and reference material data include reference values or correction factors, the laboratory shall ensure the reference values and correction factors are updated and implemented, as appropriate, to meet specified requirements

Consider a calibration certificate reporting corrections

Instrument reading (units)	Correction (units)		
100	-0.2		
110	-0.3		
120	-0.3		

The result of a measurement in which the instrument gave a reading of 110 units is obtained by adding the correction to the reading



corrected result = 110 + (-0.3) = 109.7 *units*

6.4 Equipment

6.4.12 The laboratory shall take practicable measures to prevent unintended adjustments of equipment from invalidating results.







Calibration Mode



6.4.13 Records shall be retained for equipment which can influence laboratory activities. The records shall include the following, where applicable:

a) the identity of equipment, including software and firmware version;

b) the manufacturer's name, type identification, and serial number or other unique identification;

c) evidence of verification that equipment conforms with specified requirements





d) the current location;

e) calibration dates, results of calibrations, adjustments, acceptance criteria, and the due date of the next calibration or the calibration interval;

f) documentation of reference materials, results, acceptance criteria, relevant dates and the period of validity;

g) the maintenance plan and maintenance carried out to date, where relevant to the performance of the equipment;

h) details of any damage, malfunction, modification to, or repair of, the equipment.



Section 6.3 on Facilities and Environmental Conditions Along With Section 6.4 on Equipment



This time is allocated for questions. You should have a space provided for submitting questions.





Save the Date

Next PJLA Webinar Wednesday August 26, 2020

August 2020							
S	м	т	w	Т	F	S	
						1	
2	3	4	5	6	7	8	
9	10	11	12	13	14	15	
16	17	18	19	20	21	22	
23	24	25	26	27	28	29	
30	31						

Wednesday, Aug 26th 2020

ISO/IEC 17025:2017 Section 8.7 Corrective Action

